



INSTALLATION INSTRUCTIONS

Acoustic

PINK® BATTs® SILENCER® INSULATION WALL & MIDFLOOR

Installation Instructions

Correct installation with no compression, gaps or folds is critical to ensure the performance of the Pink® BattS® Silencer® wall and midfloor insulation is not compromised.

Safety:

Each installation is unique, so prior to installation check for all hazards that may cause injury:

- Carry out any required repair work before starting installation
- Ensure there's adequate lighting to identify any hazards
- Treat all electrical cables as live, being careful not to cut or expose cables and wires
- Beware of other sharp objects (protruding nails, splinters etc.), pests (bees and wasps), loose boards and pipe work

Note: Seek professional advice if you are unsure how best to isolate the hazard or have a professional installer carry out the work on your behalf.

We recommend PinkFit® professional installers. PinkFit® are a nationwide network of professional installers who guarantee that their completed installation will meet the requirements of NZS 4246:2016.

For your local PinkFit® installer call **0800 746 534** or visit pinkbatts.co.nz/installing-pink-batts/

Installation:

Any slight irritation to exposed skin caused by the fibres in glass wool, or through their inhalation, is harmless and temporary.

However for your comfort while installing, it's recommended you wear:

- Loose fitting work clothes which cover the arms and legs
- Covered shoes
- Dust mask
- Safety glasses

For safety while installing, it's recommended you use:

- Cut resistant gloves (if knife is used)

For an efficient installation, the following tools are recommended:

- Stable working platform
- Knife
- Tape measure

To ensure Pink® Batts® Silencer® insulation performance isn't compromised, use only wall products for installing in wall applications. Ceiling products are not suitable.

- Ensure the product is installed dry
- If cutting is required, cut oversize by 5mm to ensure a good friction fit
- Ensure there are no gaps, folds or compression of the product to achieve optimal performance

For Pink® Batts® Silencer® 100mm and 75mm

- Fill gaps above and below windows and doors with off-cuts
- Do not cover vents. Insulate around vents to allow unhindered ventilation
- Fit Pink® Batts® insulation tight and close around electrical cables and pipes. It's important to minimise compression, gaps and folds in the insulation. For electrical cables and small diameter pipes, partially cut insulation and place around the cables and pipes

For Pink® Batts® Silencer® MidFloor:

- Fit Pink® Batts® insulation beneath electrical wiring and plumbing

CAUTION: Electrical cables and equipment installed prior 1989 may overheat and fail when partially or completely covered with bulk thermal insulation

Refer to NZS 4246:2016 for further information related to the correct installation of insulation and clearances.

Specification Notes

	GREENGUARD CERTIFICATION	CODE	SIZE (mm)	NOMINAL STABILISED THICKNESS (mm)	NOMINAL TOTAL AREA PER PACK (m ²)	APPROX COVERAGE PER PACK* (m ²)
Pink® Batts® Silencer® 100mm	✓	7317001	1140 X 560	100	13.2	14.9
Pink® Batts® Silencer® 75mm	✓	7317003	1140 X 560	75	17.2	19.5
Pink® Batts® Silencer® Midfloor	✓	7310051	1140 X 432	150	4.9	5.2

* Coverage relates to standard structure and actual coverage may vary

Acoustic**PINK® BATTs® SILENCER® INSULATION
WALL & MIDFLOOR****Storage and Maintenance**

Pink® Batts® Silencer® insulation should be protected from damage and weather. Store under cover in clean, dry conditions. The installed product should remain dry at all times. If the product becomes wet or damp, the source of dampness (e.g. leak in building) should be repaired and any wet or damp insulation should be removed and replaced with new insulation with an equivalent performance.

Disposal of bags

Recyclable LLDPE bags are used for packaging of Pink® Batts® Silencer® insulation. These bags are categorised as Rec 4 and can be placed in a recyclable refuse collection bin. For further details download the relevant product data sheet from pinkbatts.co.nz

Accreditations/Appraisals/CertificationsTasman Insulation New Zealand Ltd
Certified QMS

This document supersedes all previous versions and may have been superseded; is a guide only and the purchaser should ascertain the suitability of this product for the end-use situation intended and when used in conjunction with other products; and is provided without prejudice to Tasman Insulation New Zealand Ltd (Tasman) standard terms of sale. Tasman retains the right to change specifications without prior notice. Refer to www.pinkbatts.co.nz or consult Tasman for further information. Do not use this product for any application not detailed in this document. All claims about this product are subject to any variation caused by normal manufacturing process and tolerances. The liability of Tasman and its employees and agents for any errors or omissions in this document or otherwise in relation to the product is limited to the fullest extent permitted by law. Except where the consumer acquires the goods for the purposes of a business, any rights a consumer may have under the Consumer Guarantees Act are not affected. The colour PINK and Pink® are registered trademarks of Owens Corning used under license by Tasman Insulation. Batts® is the registered trade mark of Tasman Insulation.

TASMAN
INSULATION NEW ZEALAND
DISTRIBUTED BY
 Tasman Insulation New Zealand Ltd
 9-15 Holloway Place, Penrose, Auckland,
 New Zealand

pinkbatts.co.nz

These installation instructions may have been superseded. Please refer to pinkbatts.co.nz or call **0800 746 522** for the most current information.

Always.